



## Installation Instruction


WS112/W . WS112-1/W . WS112-2/W






## 2.Installation place required


The distance between Wall A and Wall B should be more than 1500mm. The parallel error between Wall A and Wall B from bottom to 2000mm height should be less than 10mm. If it's bigger than 10mm, please correct the wall. The distance between floor drain and Wall C should be less than 600mm.




3.Adjust the shower tray: Insert the waster water pipe into the drain. Then adjust the foot of shower tray to keep the shower basin surface horizontal and perpendicular to the wall.



4.1 Put the shower tray to the installation place; 2 Put the glass of backboard against the wall.







6. Install technical panel

1 Connect water and power supply.


O Insert the steam engine waste water pipe into the drain.


③Connect the earth wire to the ground or wall.







8.Install the backboard glass with shampoo holder.










- 12.<u>Install the roof:</u>A.Connect the water pipe and electric wire;B. Fix with tapping screws and install the decoration cover.









15.Install the door handle.

