Steam Room Installation Manual L52 Series (L523)

All set up dimensions are in Millimeters












No.	Components	No.	Components	No.	Components	No.	Components
1	Fan	8	Active Glass	15	Top Cover	22	Control Panel
2	Top Track	9	Shower Chain	16	Top Shower	23	Fixed Aluminum
3	Handheld Shower	10	Handle	17	Speaker	24	Steam Box
4	EdgeAluminum	11	Acupuncture Jet	18	Colorful Top Light		
5	Mirror	12	Seat	19	Storage Shelf		
6	Sliding Bar	13	Foot Massage	20	Scotland Waterfall	1	
7	Fixed Glass	14	Bottom Track	21	Changeover Switch		



01. Water Supply : one hot water pipe and one cold water pipe, Install the DN15(G1/2) shut-off value 1000mm from the floor, 0.15Mpa \leq Water Pressure \leq 0. 4MPa.

02. **Power Supply :** Steam Generator Power : 4000W, Rated Voltage : $AC220V \sim 240V / 50 \sim 60Hz$, Single-phase three-wire $3x4mm^2$ copper insulated wire, Independent electrocircuit, install only GFCI breakers with a reliable ground wire protection, Install the 30A GFCI circuit at the 1500mm wall height to connect the steam generator circuit.

03. Water Drainage: the Floor drain outlet should be \geq DN50 (2 inch), keep the same level as the ground.

04. Models with a telephone and CD, install the telephone and CD socket above the power socket.


Installation Requirement


First check the package factory code marked on crates. Numbers should match.

Second prepare the following tools : phillips screwdriver, slotted screwdriver, $6\sim30\#$ adjustable wrench, level, knife, silicone sealant, caulk gun, wood wedge, plastic hammer.

L523 Steam Room structure


Installation parts list		
M6x35 hexagon screw		10
M6x25 hexagon screw		22
M4x16 self-tapping screw		6
M4x10 self-tapping screw	(finine)	16
M4x16 screw		12
Black Washer		7+2
H1Plastic strip		10m
H9Plastic strip	\square	2
308A Magnet Sealing strip		2
A1 A2 Glass(1895x355mm)		2
B1 B2 Glass (1955x550mm)		2
C1 C2 (1835mm) ^{Top Track} Bottom Track		2
D1 D2 (1965mm) Edge Aluminum	{e]	2
E1 E2(1896mm) Fix Aluminum		2
H2 Plastic Washer		4






1. Install Tray


Move the Tray to the desired location, every ground foot nut should touch the ground, Use the leveling feet to level the tub. Insert the drain pipe into the drainage outlet. Drain should be a minimum of 2 inch dia. Refer to Pic 1





(2) line up the mid back panel holes to bathtub holes. Use M6x35 hexagon screws to connect(As Pic 3) Leave all hardware loose until unit is completely assembled.
(3) Apply silicone along the mid back panel left edge. (As Pic 3)
(4)Glue plastic washer to the left panel installation hole. Apply silicone continually along the installation holes. (As Pic 3)
(5) Use M6x25 hexagon screws to connect the Left panel to mid back panel holes.

(5) Use M6x25 hexagon screws to connect the Left panel to mid back panel holes.
Use M6x35 hexagon screws to connect the Left panel to tray holes .(As Pic 4)
(6) Use the same method to install the Right Panel.(As Pic 4)



3.Install Aluminum Frame


(1) Connect the C1 top track and C2 bottom track to E1 and E2 aluminum pieces.

Use M4x10 self-tapping screws to connect them. (As Pic 5)


- (2) Insert the A1 Glass along C1 and C2 and into E2 aluminum (As Pic 6)
- (3) Install the H2 plastic washer to the D1edge aluminum


(4) Insert the D1 edge aluminum into C1 and C2, and around the A1 Glass. Use a rubber mallet to tap lightlyinto place. Use M4x10 self-tapping screws to connect them.


(5) Use the same method to install the A2 Glass and F2 $\,$ edge aluminum



(6)Set the aluminum frame on the tray. Align the D1 and D2 aluminum edge holes to Left panel and Right panel holes. Use M4x16 screws to connect them.(As Pic 7)








5. Install Glass Door

(1)Install the eccentric gear and handle to glass B1, B2 holes, insert the 308A Magnet Sealing Strips to the B1 and B2 glass. (The edge near handle)
(2)Hang the B1,B2 upper eccentric gear on the inner top track. Turn down bottom eccentric gear to push the B1,B2 into the inner bottom track.

(3) Adjust the upper eccentric gears to align the doors, then adjust the bottom eccentric gears so that the doors move smoothly. Tighten the nuts and install the wheel caps.

(4)Insert the H9 plastic strip to the B1,B2. (As Pic 10)



7. Connect Electrocircuit

Connect Speaker, exhaust fan, and ozone and so on .

8.Sealing the shower chamber

Apply clear silicone to all seams and gaps.

9. Test

After finishing installation, connect the water and electrical supply. Make sure the steam room and bathtub function properly, with no leaks.